




**PUSH-PULL FLAP DRAWER ASSEMBLY  
(OPTIONAL)**



**4WG DRAWER ASSEMBLY  
(OPTIONAL)**




**YNTB FLAP DRAWER ASSEMBLY**




**FIXED DRAWER ASSEMBLY  
(OPTIONAL)**

<b>POSITION NUMBER</b>	<b>DESCRIPTION</b>
3	WARMER DRAWER RAIL WHEEL
4	SCREW (CIRCULAR-HEAD, 3.9*9.5, BLACK)
5	WARMER DRAWER INNER COVER
6	WARMER DRAWER PANEL (60*60,3D)
14	BOTTOM INSULATION COVER (60*60)
37	DRAWER PANEL STOPPER
39	WARMER DRAWER RAIL
67	CHASSIS BRACKET CONTACT SCREW
227	FIXED DRAWER PANEL TOP BRACKET
330	SCREW (KNURLED,M4*4)
347	DRAWER WHEEL MILE (4 WG),RIGHT \ LEFT)
348	DRAWER WHEEL MILE (4WG)
349	DRAWER WHEEL (4 WG)
368	SCREW (KNURLED, 2.9*18)
369	SCREW (KNURLED, 2.9*8,BLACK)
371	FLAP DRAWER (HINGE / LEFT)
372	FLAP DRAWER LOCKING BRACKET
373	FLAP DRAWER LOCKING (MINI LATCH)
384	FLAP DRAWER LOCKING COUNTERPART(MINI LATCH)
389	DRAWER BOX
559	FIXED DRAWER PANEL BOTTOM BRACKET(NEW G)
<p>"The exploded views given in this document are generic.They include all possible versions of the product. For specific part codes, please refer to the bom list of regarding model."</p>	




FLAT TYPE OVEN DOOR - POSITION NO 376 (OPTIONAL)




220,239,240 is for Removable Third Glass Versions  
 262,67 is for Removable Glass Versions


FLAT TYPE OVEN DOOR WITH FULL GLASS STRUCTURE - POSITION NO 377 (OPTIONAL)




SOLID TYPE - POSITION NO 395 (OPTIONAL)



HANDLE ASSEMBLY GROUP -  
POSITION NO 49  
(OPTIONAL)



INTERVAL GLASS  
(ONLY FOR FLAT TYPE OVEN DOOR  
WITH FULL GLASS STRUCTURE)  
(OPTIONAL)



SOLID TYPE - POSITION NO 54 (OPTIONAL)

**OVEN DOOR OUTER GLASS ASSEMBLY PARTS**

<b>POSITION NUMBER</b>	<b>PART NAME</b>
4	SCREW (KNURLED, 3.9*9.5, BLACK)
49	HANDLE ASSEMBLY GROUP
50	INNER GLASS ASSEMBLY
51	INNER LID TOP CONTACT SCREW
52	OVEN DOOR HINGE
53	OVEN DOOR HANDLE ASSEMBLY STUD
54	OUTER GLASS ASSEMBLY
55	HANDLE BRACKET / BRACKET WITH CAP
56	HANDLE BODY
67	REMOVABLE INNER GLASS SPRING CONTACT SCREW
75	NEW G. FS OVEN DOOR SILICONE STOPER
107	GRADUAL/FLAT WASHER
173	DOUBLE GLAZED OVEN DOOR METAL TRIM CONTACT SCREW
204	HANDLE TAP
211	HANDLE ASSEMBLY GASKET
220	INTERVAL FRONT PANEL SPRING
237	DOUBLE GLAZED OVEN DOOR METAL TRIM
238	OVEN DOOR HANDLE CONTACT SCREW
239	HANDLE FIXING BUSH
240	SILICONE WASHER
262	REMOVABLE INNER GLASS SPRING ( LEFT / RIGHT )
293	DOOR LOCK PIN
302	HANDLE BRACKET CONTACT SCREW
329	WASHER
367	THERMOMETER GROUP
375	SOLID TYPE OVEN DOOR ( FLAT / OBLIQUE )
376	SOLID TYPE OVEN DOOR ASSEMBLY
377	OVEN DOOR GROUP

"The exploded views given in this document are generic. They include all possible versions of the product. For specific part codes, please refer to the bom list of regarding model." 31 07 2013