

SPARE PART LIST FOR MODEL LS60070X stainless steel

NO.	SAP CODE	English
1	218210000273	External Door
2	228210000272	Casing for Wiring
3	258210000273	Wiring
4	208210000992	Left-Right Hinge
6	228210001416	Lower Seal Holder
7	598210000013	Lower Seal of Inner Door
8	208210001205	Inner Door
9	258210000025	Detergent Dispenser
10	598210000177	Tub Tasket
12	218210000258	Tub Bottom Bitument
13	577400090023	OTK500
14	208210001219	Sump Assembly
15	598210000046	Block for Draining Pump
16	278019000413	Draining Pump
17	598210000151	Sump Seal
18	228210001413	Sump Deflector
19	258210000011	Temperature Sensor
20	598210000021	Seal for Turbidity Sensor
21	228210000063	Overflow Hose
22	228210000037	Overflow Launder
23	598210000146	Guide Holder Seal
24	208210000799	Softener Cap Assembly
26	218210000315	Guide Reinforce
27	228210000827	Guide Holder
28	228210000826	Guide Wheels
29	218210000523	Left Side Panel

SPARE PART LIST FOR MODEL LS60070X stainless steel

NO.	SAP CODE	English
30	598210000004	Rubber Tubbe for Heater
31	577400090022	OTK381
32	258210000119	Heating
33	598210000169	Inlet Rubber Duct for Washing Pump
34	577400090019	OTK396
35	598210000273	Motor Damping Rubber
36	218210000529	Right Side Panel
37	278049000047	Washing Pump
38	577400090024	OTK361
39	518020000077	Overflow Float
40	228210001707	Overflow Holder
41	258210000165	Overflow Microswitch
42	598210000006	Outlet Rubber Duct for Washing Pump
43	598210000111	Outlet Hose for Softener
44	228210000055	Hinge Line
45	228210000389	Adjustable Foot
46	575000090456	Door Spring
47	258210000151	Water Inlet Value
48	577400090020	OTK175
49	598210000153	Inlet Hose for Air Breaker
50	218210000038	Door Lock Hook
51	228210000040	Claspe Holder
52	228210000066	Air Inlet
53	598210000003	Seal for Air Breaker
54	208210001130	Tub Assembly
55	228210001071	Air Breaker Nut

SPARE PART LIST FOR MODEL LS60070X stainless steel

NO.	SAP CODE	English
56	228210000853	Nut for Air Breaker
57	598210000066	Air Breaker Seal
58	598210000065	Seal for Air Breaker
59	258210000094	Air Breaker
60	577400090008	Clamp (ø14.9*ø1.8)
61	258210000095	Softener
62	228210000839	Softener Nut
63	228210001438	Plastic Base
64	598210000156	Damping Tray for Inner Tub
65	258210000283	Power Cord
66	228210000393	Holder for Water Pipe
67	598210000031	Draining Hose
68	228210000392	Pipe Holder
69	598210000083	Inlet Hose
70	228210000080	Top Panel Holder
71	228210000090	Side Bracket of Top Panel
72	228210000089	Front Bracket of Top Panel
73	228210000091	Rear Bracket of Top Panel
74	248210000020	Roof Wooden
75	208210000832	Roof
78	218210000028	Upper Rear Crosspiece
79	518020000075	Pad for Upper Rear Crosspiece
80	228210000856	Pipe Casing
81	208210000897	Lower Sprayer Assembly
82	228210001192	Extractable Cup
83	208210000996	Inner Pipe

SPARE PART LIST FOR MODEL LS60070X stainless steel

NO.	SAP CODE	English
84	228210001189	Micro Filter
85	228210001188	Filter Support
86	218210000615	Flat Filter
87	228210000943	Watershed
88	598210000001	Seal for Watertshed
89	228210000855	Upper Sprayer Pipe Holder
90	598210000053	Matching Seal
91	228210001415	Matching Piece
92	598210000052	Block for Upper Sprayer
93	228210000854	Upper Sprayer Pipe
94	208210001040	Upper Sprayer Assembly
95	228210000824	Basket Wheel Holder
96	228210000823	Wheels of Upper Basket
97	208210001114	Upper Basket Assembly
99	228210000828	Wheels of Lower Basket
100	228210001284	Holder for Basket Wheel
101	208210000938	Lower Basket Assembly
102	208210001587	Cultery Basket
103	228210000835	Basket Guide Rear Block
104	228210000834	Basket Guide Front Block
105	218210000357	Upper Basket Guide
106	253039000003	Microswitch
107	208210001601	Door Lock Assembly
108	218210000020	Dispenser Holder
109	268210000749	Main PCBA
110	228210001445	PCB Box

SPARE PART LIST FOR MODEL LS60070X stainless steel

NO.	SAP CODE	English
111	228210001458	Button
112	228210000439	Plastic Handle
113	228210001452	Control Panel
114	228210001920	Display
115	228210001460	Baseboard
116	228210000849	Draining Hose Hanger